MASON MASON SAFE

It is 20 years since we made our major contribution to the safety of the marketplace by introducing

PEROXIDE CURED EPDM AND DuPONT KEVLAR® TIRE CORD REINFORCEMENT TO EXPANSION JOINT CONSTRUCTION

Safeflex expansion joints are molded and vulcanized in hydraulic presses. This high pressure process produces a smooth finished product with outstanding adhesion between the cover, reinforcement and tube.

Most of our competitors still use Natural Rubber impregnated Nylon tire cord between sulfur cured, EPDM covers and tubes. This construction becomes brittle with age at higher temperatures, so we changed from Nylon to Kevlar[®], as Kevlar[®] has a higher modulus that minimizes swell and elongation, and outstanding temperature tolerance up to 250°F (121°C).

Changing the EPDM curing system from sulfur to the slower, more expensive peroxide method raised the high temperature safety factor, as well as other physical properties. We force EPDM between, over and under the Kevlar® cords. This makes Safeflex superior as cover, reinforcement and tube are all homogeneous. Natural Rubber has been completely eliminated to improve aging and temperature tolerance.

Another serious problem had been the body pulling out of the flange because flexible bead wire does not provide sufficient retention. Our answer was to wrap the tire cord around a solid steel ring in place of the cable. In 20 years, the steel ring has never pulled through.

Sealing pressure is amplified by the ductile iron flanges that rotate inward around solid exterior stops. The split flanges are hooked together to prevent spreading.

Safeflex was the culmination of 25 years of application experience and a driving desire to eliminate all possible failures. These improvements were costly, but the engineering and contracting communities and the consumers they serve have always been receptive to our improved longer lasting and safer products. Why risk failure when there is a better product and the cost difference is meaningless against safe extended life. Water burst and leakage failures are catastrophic in downtime and property damage as sometimes they come close to being waterfalls.

IN BRIEF, SAFEFLEX IS SAFE BECAUSE...

- All Safeflex Expansion Joints are factory tested to 150% of rated pressure before shipment.
- Kevlar[®] high temperature tolerance is outstanding.
- Peroxide cured EPDM covers and tubes with Kevlar reinforcement are superior to sulfur cured EPDM, Natural Rubber, and Neoprene Nylon reinforced bodies at all temperatures.
- Kevlar[®] reinforcement wrapped around solid steel rings cannot pull through the flanges.
- Sealing pressure is higher using external stops as rotation points.

important as well.

capabilities are very

SAFEFLEX SFDEJ SFDEJ double sphere con-

nectors are always our first

body has better volumetric

response to sound pressure waves and provides superior

sound attenuation. In seismic

zones the extra movement

recommendation. The longer

SAFEFLEX SFEJ

SFEJ single spheres are used where there is minor expansion, no seismic considerations or space and cost controls.

SAFEFLEX SFDCR

SFDCR twin sphere reducers eliminate the need for cast iron or steel transition pieces usually found on both ends of pumping systems. Since steel reducers are eliminated, there are space, cost and labor savings. The SFDCR has a wide range of applications.

SAFEFLEX SFU

SINGLE-SPHERE UNION CONNECTOR

SFU single spheres are more than adequate for both sound reduction and movements in smaller pipelines. 3 bolt flanges increase sealing pressure and eliminate pullout common to threaded pipe coupling ends poorly adapted to this service.

LOCK

FLANGE

16" - 24" SFDEJ Sizes added in 2013 in response to demand

Solid Steel Ring



SAFEFLEX SFDEJ Dimensions and Allowable Movements

Pipe	Face	Pipe	Face	Allowable Movements							
Size (in)	to Face (in)	Size (mm)	to Face (mm)	Angular (degrees)	Comp (in)	ression <i>(mm)</i>	Elong (in)	gation <i>(mm</i>)	Trans + (in) +	verse (mm)	
11/ 2 21/ 3 4 5 6	⁷ 2 7 7	40 50 65 75 100 125 150	175	36 34 32 30 28 24 22	11/4	32	3/4	19	3/4	19	
8 10 12	8	200 250 300	200	20 18 16	11/2	38	7/8	22	7/8	22	
14	10	350	250	14	15/8	41	1	25	1	25	
16 18	11 11	400 450	275 275	13 12	13/4	44	1	25	1	25	
20 24	12 12	500 600	300 300	11 10	17/8	47	11/8	28	11/8	28	

16" – 24" SFDEJ twin sphere sizes added in 2013 in response to demand.

SAFEFLEX SFEJ Dimensions and Allowable Movements

Pipe	Face	Pipe	Face	Allowable Movements								
Size to Face (in) (in)		Size (mm)	to Face (mm)	AngularCompression(degrees)(in)		Elong (in)	gation <i>(mm)</i>	Transverse + (in) + <i>(mm)</i>				
11/2 2 21/2 3 4 5	4	40 50 65 75 100 125	100	21 20 19 18 17 16	5/8	16	1/2	12	3/8	9.5		
6 8 10 12	6	150 200 250 300	150	15 14 13 12	1	25	5/8	16	5/8	16		
14 16 18 20	9	350 400 450 500	225	10 9 8 7	11/8	29	7/8	22	7/8	22		
24	10	600	250	6	11/8	29	1	25	1	25		

SAFEFLEX SFU Dimensions and Allowable Movements

Pipe Face	Pipe Face	Allowable Movements							
Size to Face (in) (in)	Size to Face (mm) (mm)	Angular (degrees)	Compression (in) <i>(mm</i>)	Elongation (in) (mm)	Transverse + (in) +(mm)				
3/4 7 1 7 11/4 8 11/2 8 2 8	2017525175322004020050200	25 24 23 22 21	3/4 19	3/8 10	3/8 10				

SAFEFLEX SFDEJ, SFEJ, SFDCR and SFU KEVLAR[®] REINFORCEMENT Standard and High Pressure Construction-Pressure Reduction at Higher Temperatures

Construction Max. Vacuum Minus Types & Sizes Nominal Rating In PSI at: Nominal Rating In Bar at: (in) (mm) 170°F 190°F 210°F 230°F 250°F 77°C 88°C 99°C 110°C 121°C in Hg Bar SFDEJ Standard 250 245 235 225 17 16.5 16 15 14 14" 0.5 215 11/2" - 16" 40 - 400mm SFDEJ Standard 180 175 170 165 155 12 11.5 11 10.5 10 14" 0.5 18" - 24" 450 - 600mm SFDEJ High Pressure 300 285 22" 335 325 315 21 20 19 0.7 11/2" - 16" 40 - 400m SFDEJ High Pressure 22" 0.7 225 220 210 200 190 15 14.5 14 13.5 13 18" - 24" 450 - 600mm SFEJ Standard 250 245 235 225 215 17 16.5 16 15 14 18" 0.6 11/2" - 16" 40 - 400mm SFEJ Standard 180 175 170 165 155 12 11.5 11 10.5 10 18" 0.6 18" - 24" 450 - 600mm SFEJ High Pressure 11/2" - 16" 40 - 400mm 335 300 23 21 20 19 29" 1.0 325 315 285 SFEJ High Pressure 225 220 210 200 190 15 14.5 14 13.5 13 29" 1.0 18" - 24" 450 - 600mm SFU Standard 235 225 17 16 15 14 18" 0.6 250 245 215 All Sizes SFDCR Standard 250 245 235 225 215 17 16.5 16 15 14 14" 0.5 All Sizes

OTHER SFU FITTING OPTIONS



SAFEFLEX SFU-SS Stainless Steel Threaded Ends



See

Page 4



Brass Threaded Ends



Connectors installed in piping to allow for expansion or contraction must be anchored on both ends of the piping run. They need no control rods or cables. Should controls be used, they must be adjusted so the gap between the nut and the washer allows for full outward travel of the expansion joint. Piping movements must be within the tabulated allowables.

Connectors installed in unanchored piping or connected to isolated equipment only require control rods or cables for pressures as tabulated only if noted under lower right hand table. Noise Transmission Cheap competitive Control Rods with small, thin washers &

no rubber

bushinas

Type CR and ACC control rods and cables are very different than the average rod and rubber washer arrangement. Our sets are all made with oversized washers on the ends to limit the maximum loading on the rubber materials to 1000psi (70kg/cm²). Competitive systems use 1/4" (6mm) rubber washers that are the same size as the small standard washers. Thrust forces are so high that standard washers extrude and fail. In addition to the increased area and thickness of the rubber, all our control rod washers are molded with rubber bushings so the rod or cable cannot contact the steel restraining plates and short circuit the system acoustically.

Installation Instructions for Safeflex SFDEJ & SFEJ Install only within machine rooms.





CAUTION: This extension procedure is an ABSOLUTE must on all connections to spring mounted systems such as pumps (when control rods are not used) or the pressure may compress the springs solid under the pumps or shift the foundation.

127/8

127/8

20

24

12

12

123/8

123/8

125/8

125/8

316

All high pressure connectors should have control rods or cables set at maximum expansion joint allowable elongation.

SFDEJ AND SFEJ CONNECTORS USED AS NOISE AND VIBRATION DAMPENERS ONLY INSTALLED AND IN UNANCHORED PIPING WILL GROW IN RESPONSE TO THE PRESSURE AS SHOWN BELOW. Adjust the spring mountings so the equipment is at the proper level. Leave a space between pipe flanges equal to the lengths shown below and draw the connectors out evenly with the flange bolts. Spring supported equipment may lift in response to the tightening so the connector may not be fully extended. When the connector is at operating pressure the system will return to the original position.





Only Use Control Rods or Cables if:

- 1. Expansion Joints cannot be preextended and could cause problems to pipe or equipment.
- 2. As an added precaution.



SAFEFLEX SFDCR Dimensions and Allowable Movements

Pipe	Face	Pipe	Face to Face <i>(mm)</i>	Allowable Movements							
Size (in)	to Face (in)	Size (mm)		Angular (degrees)	Com (in)	oression <i>(mm)</i>	Elor (in)	ngation <i>(mm)</i>	Trans (in) (verse (mm)	
3x2 3x21,	6 /2 6	75x50 75x60	150 150	25	1	25	5/8	16	5/8	16	
4x3 5x4	7 8	100x75 125x100	175 200	20	11/4	32	3/4	19	3/4	19	
6x4 6x5 8x6 10x8	9 9 11 12	150x100 150x125 200x150 250x200	225 225 275 300	15	15/8	41	3/4	19	7/8	22	

SAFEFLEX SFDCR

Pressure Extension Table 250 lb 17 Bar Construction

Pipe Size	0 psi	100 psi	200 psi	250 psi	Pipe Size	0 Bar	6.8 Bar	13.6 Bar	17 Bar
(11)		Face to	Face Ler	ngth	(11111)	Face to Face Length			
3x2	6	61/8	6 ³ /16	61/4	75x50	150	153	155	156
3x21/2	6	61/8	63/16	61/4	75x60	150	153	155	156
4x3	7	71/8	71/4	73/8	100x75	175	178	181	185
5x4	8	83/16	83/8	81/2	125x100	200	205	210	212
6x4	9	93/16	93/8	91/2	150x100	225	230	235	237
6x5	9	93/4	97/16	99/16	150x125	225	231	236	239
8x6	11	113/8	111/2	115/8	200x150	275	285	287	291
10x8	12	121/2	123/4	13	250x200	300	312	319	325

Installation Procedures for Safeflex SFDEJ, SFEJ, SFDCR and SFU

Although Safeflex is as safe possible, It is our general recommendation that flexible connectors are always installed on the equipment side of the shut-off valve, and they are not used in pipe lines that pass through finished ceilings where water damage to the structure or the equipment below can be extensive.

Install only where leakage or failure will not result in injury or property damage.

- 1. a. Expansion joint rubber flanges must be in contact with a flat surface. Normal 1/16" raised face is o.k. Unacceptable depressions or protrusions are typical of victaulic or similar flanges.
 - b. Flange stops must bear on full diameter mating flanges.
 - c. Rubber flanges will not retain loose elements in valve bodies that rely on contact with a steel flange. For example, some check valves are manufactured with brass inserts positioned by screws. When mating steel flanges with these valves, there is no problem. However, with a rubber connector, it cuts the rubber face and can cause failure, leakage or brass insert escape.
- 2. Any of the above conditions must be corrected by installing a full diameter steel flange drilled to standard dimensions so the flange bolts pass through it. The I.D. matches the I.D. of the piping. Minimum Plate Thickness is as follows: 1/2" thick for 1-1/2" to 8" pipe, 3/4" thick for 10" to 18" pipe, and 1" thick for 20" to 24" pipe. Gasket between this filler flange and the mating steel flange.
- 3. Before installing the connector be certain that all surfaces are clean and there are no sharp edges of any kind on the steel flanges. No gasket is required. Apply a thin film of graphite dispersed in glycerin or water to the face of the rubber flanges before installing. No other type of lubricant or seal should be used on the flange face. The graphite prevents the rubber from adhering to the metal flange so that the rubber joint can be removed without damage, should it ever be necessary.
- 4. If the connector is to be installed in a system where the operating pressures do not dictate the use of control rods, but the connector is to be pre-extended to allow for growth under pressure, the gap between the piping flanges should be large enough to allow for the growth as indicated on the operating pressure chart.
- Expansion joints installed for expansion and compression applications should be installed at normal length. Check allowable movements against design requirements between anchors.
- 6. Check temperature and pressure ratings and never exceed them.
- 7. Check for chemical compatibility with the ordered material.
- Do not weld near the expansion joints or weld the steel flanges to the piping after the expansion joints are installed. This will either burn or seriously damage the expansion joints.

- 9. Although the expansion joints will readily adjust themselves to misaligned flanges within the specified movements, they should not be installed where there is more than 1/8" of initial misalignment or lack of parallelism in the expansion joints.
- 10. Slide the connector into position and insert all the flange bolts. The rubber face must be centered exactly on the opening. Be sure that the bolts are inserted with the heads facing the rubber and the nuts on the outside so they are on the outside of the mating flange. If it is impossible to insert the bolts in this direction, the tightened end of the bolt must not protrude more than 1/8" beyond the inside nut. Larger protrusions may result in the bolt cutting into the rubber cover.
- 11. After all bolts are inserted, make them finger tight and then proceed to adjust them evenly in a circle. Tighten the bolts to 75% of the maximum recommended torque for the bolt size until all bolts have the same tightness. Tightness may be increased if there is joint leakage.
- 12. All rubber materials tend to relax over a period of time. It is good practice to check the tightness of the bolts for the 75% torque about two weeks after installation, and in extreme cases, particularly when a line is heated up and allowed to cool repeatedly it is advisable to continue to check bolt tightness on a monthly basis until such time as the last check shows no further tightening is required.
- 13. Allowing the bolts to loosen may cause leaks.
- 14. Insulation on cold lines should be installed for easy removal to facilitate retightening.
- 15. In order to prevent heat buildup, expansion joints in hot lines should not be insulated.
- 16. While our expansion joints are guaranteed for a period of one year and designed for many years of service, it is suggested that expansion joints are replaced every five years. Cover cracking is of no significance and only cosmetic.

SFU Installation Instructions (See general precautions above)

- 1. Attach flanges to piping so length between inside flange faces is equal to face to face length of rubber section of the SFU.
- 2. Insert center section of the SFU and the 3 bolts on each end. Tighten evenly to 75% of torque value.
- 3. Retighten as in 12 above.

IT IS IMPORTANT TO FOLLOW ALL OF THE NUMBERED INSTRUCTIONS TO AVOID NEEDLESS PROBLEMS.

MASON INDUSTRIES, Inc.
350 Rabro Drive, Hauppauge, NY 11788 • Reply to:PO Box 410, Smithtown, NY 11787
631/348-0282 • FAX 631/348-0279 • Web: www.mason-ind.com • E-mail: Info@Mason-ind.com